## Siemens HVAC Products

## RDE Programming Instructions.

Page 1

Front Panel:	Up Down Progr	ramming buttons	\$	
	Prop	grammed Heatin	g	
	Con	nstant Heating		
	C Ec	onomy Heating '	Temperature or	OFF
Open side co	over on right hand	l side		
To Set Clock.				
Press Adjust clock to	button current time, using t	the top buttons		
Once the time I	nas been set, leave fo	r 5 seconds.		
To Set Curren	t Day.			
Monday 1	Tuesday Wednesda 2 3	ay Thursday Fri 4 5	day Saturday S 6	Sunday 7
. •	button ay is Wednesday pre onds.	ss Up Down bu	ittons until the nu	mber 3 is flashing,
To Set Heating	g Temperature.	茶		
Press ≉ Adjust to requi	button red temperature usin	gthe   AUp	<sub>n</sub> buttons, leave	for 5 seconds
	ny Heating Temper		n ·	
Press (	button			
Adjust to requi	red temperature usin	g the Down 1	outtons, leave for	r 5 seconds.
NB: The Econo	omy Heating setting	can be set to OFF,	press the ( b	outton and set to 5°C
				t appear on the displa
The thermostat	is now working to th	he 🔆 Heating setp	oint or is OFF	

## Siemens HVAC Products

## **RDE Programming Instructions.**

Page 2 To Set Daily Times Move front vertical slider to the position, open side door and Press the button Time setting starts from 00:00 in the morning. Screen will look like this Flashing 00:00 Upper Blocks - Heating On Lower Blocks - Economy Heating Heating On Periods Economy Heating Periods Time - Ohrs to 24hrs 12 Press the U button for the Economy Heating or off periods, keep pressing ( to increase time Press the 🔆 button for the On periods, Keep pressing 🌟 to increase On time Example the screen blocks will bok like this for the following times Set for Day 1 Economy Heating or OFF 00:00 to 06:00 Heating ON 06:00 to 10:00 Economy Heating or OFF 10:00 to 18:00 Heating ON 18:00to22:00 Upper Blocks - Heating On Lower Blocks - Economy Heating or Off Time - Ohrs to 24hrs If you make a mistake press the button and start again. When desired On, Off's are programmed for that day Press button The controller will move to day Repeat setting ON and Off times as above, when times are set for day and you will be moved to day repeat as above. Move to next day by pressing the < button, repeat for all days (1 to 7) Program all 7 days, then press the button, to exit programming.

settings, indicated by the blocks on the bottom of the screen. To check the other days press the 1.7 day button and move through the days.